

## **Instructions:**

- On the bottom side of the base, use firm pressure to push the wheels into place. Alternate between the locking and non-locking wheels.
- Place base wheel-side down on a level surface, and stack your planter on top. Grip your planter along the side and move or rotate slowly.
- Lock the three locking wheels when stationary for maximum stability. Do not use on an uneven surface.

Questions? Contact us at support@greenstalkgarden.com